

Frequently Asked Questions

- [DT 4000 ELD Information Flyer](#)
 - [DT Video Information Flyer](#)
 - [DT Mobile Information Flyer](#)
 - [Dont Gamble with ELD Compliance](#)
 - [Can an ELD be set to 15 minute time intervals?](#)
 - [Can I change a Driving status to a Non-Driving status?](#)
 - [Can I fix the inaccurate camera time stamps?](#)
 - [Does DriverTech's ELD have Anti-Virus software?](#)
 - [Does DriverTech have a data restoration policy?](#)
 - [Driving and Motion as Defined via Vehicle Performance and HOS](#) — For Vehicle and Driver Performance: Vehicle is deemed to be driving after it has been at rest and vehicle has moved a 1/2 mile. For HOS: Vehicle is deemed to be driving after it has been at rest and vehicle has moved the distance specified as 'Minimum Drive Distance' in the Web Portal (defaults to 1/10th mile).
 - [DTNav, typing in a name that starts with "South"](#)
 - [ELD Library and LibrarySync](#)
 - [Can I use the same description with all versions of a specific document?](#) — Concerning document descriptions throughout versions.
 - [How can I tell if the unit received the new content or not?](#) — Concerning receipt of the library's files via the unit.
 - [How do I set up the document title and description the driver sees?](#) — How to setup the document title and description that the driver will see in the library.
 - [If I just upload the content I want the driver to see will it just show the file name for the file?](#) — Regarding file names and descriptions when sending to a driver
 - [Is there a way to organize the library by a category name to make it easier to find documents?](#) — Concerning library file organization.
 - [What if I want a file to be in the Library of a specific Truck?](#) — Concerning different library files for specific vehicle groups
 - [What is the maximum file name length?](#) — Maximum file name length for library articles
 - [What is the maximum path length?](#) — The maximum path length for a library entry.
 - [When I need to update a file can I just use the same file name?](#) — Basic guidance on file name updates.
 - [FleetWatcher, How does it determine which speed reading will be reported?](#) — An explanation of how FleetWatcher reports speed data.
 - [FleetWatcher, How do I make a form or macro?](#) — A link to instructions concerning how to create a form /macro in FW.
 - [FleetWatcher, How often do HOS logs and Events and Positions update?](#) — How HOS and Events and Positions are updated on FleetWatcher.
 - [FleetWatcher, Is There a Basic Template for Terminal Settings Changes?](#) — A basic template for making terminal settings changes in FleetWatcher.
 - [FleetWatcher, New Customer Setup \(Checklist\)](#) — Checklist for new customer FleetWatcher setup.
 - [FleetWatcher, Where do I find the yearly miles driven for a truck/driver?](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [FleetWatcher: Can I enter a driver's name containing punctuation?](#)
 - [FleetWatcher: Why do I see white loading screens and secure content popups?](#) — Fixing white loading screens and security messages in FleetWatcher.
 - [FleetWatcher. Where the Reports are, and how they are used.](#)
 - [Health Check, How is it Done?](#)
 - [How are Speeding Alerts Created?](#) — How speeding alerts are created.
 - [How can a driver combine their on-duty not driving status on an ELD, with Driving?](#)
 - [How can I change my Co-Pilot resolution back to normal?](#) — Steps to follow to reset Co-Pilot resolution back to normal
 - [How can I change the backlight/volume on my TruckPC?](#) — How to change settings of the unit. Test
 - [How does Daylight Savings Time \(DST\) work with my ELOGs?](#) — How the unit factors in Daylight Savings Time for Spring and Fall
 - [How does the TruckPC detect driving?](#) — States how the TruckPC detects driving/movement from the truck
 - [How does the Truck PC go from Driving to On-Duty automatically?](#)
 - [How does Unassigned Driving Work?](#) — How unassigned driving works and applies to the driver's logs if applicable
 - [How do I add remarks to a driving status?](#)
 - [How do I change the color scheme?](#)
 - [How do I find my truck number in the DT unit?](#)
 - [How do I know that DriverTech's ELD is registered with the FMCSA?](#)
 - [How do I Show My Logs to Law Enforcement?](#) — How to enter and exit Roadside Audit Mode when being pulled over.
 - [How do I use the Agricultural Exemption](#)
 - [How long are Hours of Service records retained?](#) — Data Retention policy.
 - [How to Approve or Reject log edits from the ELD](#)
 - [How-to change the truck number on your device](#) — When asked to register your device.
 - [How-to Use the Co-Driver Feature](#) — Describe when someone would need this information. For example "when connecting to wi-fi for the first time".
 - [How Will the Truck-PC Detect Driving \(Starting December 2017\)?](#) — How the Truck-PC will detect driving with the new ELD mandate in December 2017.
 - [If I turn the TruckPC off and start driving, will it record my drive time?](#) — Explains what happens when the unit senses the truck ignition is turned ON
 - [I received a low memory warning. What should I do?](#) — What to do when receiving a low memory message on the unit
 - [My touchscreen is not responding. How can I fix it?](#) — A link to the troubleshooting article concerning an unresponsive touchscreen.
 - [My unit is not communicating, how can I fix it?](#) — Fixing a no communication issue.
 - [My unit is showing the wrong time. How can I fix it?](#) — Why does my unit show the wrong time?
1. A-B
- [add](#)
 - [aeris](#)
 - [answer](#)
 - [antenna](#)
 - [app](#)
 - [approved](#)
 - [arrive](#)
 - [audit](#)
 - [auto-arrival](#)
 - [backlight](#)
 - [based](#)
 - [basic](#)
 - [bcb](#)
 - [beginning](#)
 - [bol](#)
 - [bootup](#)
 - [bsod](#)
 - [bug](#)
2. C
- [cable](#)
 - [cables](#)
 - [calibration](#)
 - [callout](#)
 - [camera](#)
 - [canada](#)
 - [canned](#)
 - [card](#)
 - [cell](#)
 - [certify](#)
 - [change](#)
 - [codes](#)
 - [co-driver](#)
 - [codriver](#)
 - [comms](#)
 - [communication](#)
 - [company](#)
 - [completed](#)
 - [conversion](#)
 - [copilot](#)
 - [crash](#)
 - [create](#)
 - [crossing](#)
 - [current](#)
 - [customer](#)
 - [cycle](#)
3. D
- [data](#)
 - [dataretention](#)
 - [deceleration](#)
 - [details](#)
 - [detect](#)
 - [deutsch](#)
 - [device](#)
 - [diagnostic](#)
 - [diagnosticevent](#)
 - [display](#)
 - [dot](#)
 - [download](#)
 - [drive](#)
 - [driver](#)
 - [drivers](#)
 - [drivewyze](#)
 - [driving](#)
 - [dt1000](#)
 - [dtcamera](#)
 - [dtcore](#)
 - [dtlibrary](#)
 - [dtmobile](#)
 - [dtnav](#)
 - [dtscan](#)
 - [dtvideo](#)
 - [duplicate](#)
 - [dvir](#)
 - [dvr](#)
4. E
- [ecm](#)
 - [eld](#)
 - [email](#)
 - [end](#)
 - [enforcement](#)

Frequently Asked Questions

- [The JBUS data information is not recording on my TruckPC. What should I do?](#) — What to do when JBUS is not recording on the unit
 - [What are the exceptions to the HOS regulations?](#)
 - [How do the HOS Timers calculate?](#)
 - [What are the most commonly used Idle fields?](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [What baud are DriverTech units set up for?](#) — What baud for DriverTech units?
 - [What can I do if my unit cannot send or receive messages?](#) — Troubleshooting messaging issues.
 - [What constitutes a long/mid/short idle in the reporting?](#) — Idle times explained.
 - [What does a driver need to do when they see diagnostic errors?](#)
 - [What does DriverBase.BDeleted mean in Change Auditing?](#) — Defining DriverBase.BDeleted in the Change Auditing Report
 - [What does the driver do on their end to register a DT unit?](#)
 - [What does Violation 128 mean?](#)
 - [What do the icons in the Log Overview report mean?](#)
 - [What is "Yaw Control via Engine" and "YC Brake Control"?](#) — An explanation of yaw control via engine and YC brake control.
 - [What is automatically recorded by the ELD?](#)
 - [What is DriverTech's recommendation as far as Hydra or Deutsch cables?](#)
 - [What is DriverTech's recommendation as far as Yard Move and Personal Use.](#)
 - [What is Logging Malfunction \(2\)?](#) — An explanation of Logging Malfunction (2)
 - [What is Logging Malfunction \(3\)?](#) — An explanation of Logging Malfunction (3)
 - [What is Logging Malfunction \(4\) ?](#)
 - [What is Required to Trigger an Auto-Arrival \(Workflow\)?](#) — What triggers an auto-arrival in workflow?
 - [What is the FMCSA's definition of Harassment?](#)
 - [What is the RMA diagnostic fee?](#)
 - [What new information is on the Drive-Safe screen with 6.01.04+?](#) — Breakdown of new Drive-Safe screen with DTCore 6.01.04+
 - [What should I show a DOT officer while being inspected?](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [What triggers an event that is recorded by the camera?](#)
 - [When do my logs/current totals update?](#) — Explains when the logs and current totals update in FleetWatcher
 - [When I press anywhere on the screen, only the bottom left corner lights up. How do I fix it?](#) — What to do when only the symbol key lights up when touching anywhere on the screen
 - [When I touch anywhere on the screen, only the bottom left corner lights up. How do I fix it?](#) — What to do when only the symbol key lights up when touching anywhere on the screen
 - [Where can I find the details on my current trip?](#) — Brief steps for locating trip information.
 - [Where Does State Mileage go if a Unit Was Unplugged While Crossing State Lines?](#) — An example explaining state mileage in regards to sensor jumps.
 - [Which is the current software version?](#) — A list of the latest software (DTCore) versions.
 - [Which software version is my unit running?](#) — How to locate your unit's software version.
 - [Which Web Browsers for FleetWatcher Does DriverTech Support?](#)
 - [Who can Certify an HOS log?](#)
 - [Who must comply with the ELD rule?](#)
 - [Truck year 2000 addendum](#)
 - [Why am I being auto-removed from Yard Move?](#)
 - [Why am I not able to use the Co-Driver feature?](#) — Information on the functionality of the Co-Driver feature
 - [Why am I not receiving Workflow Messages?](#) — Workflow troubleshooting steps.
 - [Why are my Personal Use miles not resetting?](#) — How to reset Personal Use miles for HOS logs
 - [Why are my State Miles Showing on the Wrong Date?](#) — How to troubleshoot the State Mileage Report data
 - [Why are unassigned driving events \(and other events\) showing up on the logs of multiple drivers?](#)
 - [Why are violations from a different month showing up in my report for the month I chose?](#) — Concerning violations and the month they are reported.
 - [Why can't I add a status when I stop driving?](#)
 - [Why can't I use the "add" button when I stop driving?](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [Why did my workflow go to my Inbox and not my Work tab?](#)
 - [Why does my unit not ask me to fill out a DVIR when I go Off-Duty End of Shift?](#) — What to do when the unit does not ask the driver to enter a DVIR when going Off-Duty
 - [Why does the Personal Use Report have instances with 0 miles?](#) — Explanation of how a Personal Use record could show 0 miles on the Personal Use Report.
 - [Why do I see events from other trucks on my log for today?](#) — Lists the FMCSA article and explanation for status events on a driver's log for multiple trucks.
 - [Why do the HOS logs stop halfway through the day?](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [Why is my unit requesting registration after it has already been registered?](#) — How to fix registration issues.
 - [Why is my unit shutting down while I'm driving?](#) — Lost power while driving?
 - [Why isn't my 70 hour clock being calculated correctly \(US-8\)?](#) — 70 hour calculation on US-8.
 - [Why was I put on the drive line before I started driving?](#) — An explanation of how the unit decides "driving" status.
 - [Why won't my TruckPC turn on?](#) — Troubleshooting steps for a unit with no power.
 - [Helpful Pages for New Customers](#)
 - [How does the unit warn for Personal Use limits?](#)
 - [Forms Q&A](#) — Enter a very brief description of what this page accomplishes or explains. ex. This is how to create a troubleshooting article.
 - [How do I troubleshoot my GPS \(Rev 7\)?](#)
- [erld](#)
 - [escalate](#)
 - [escalation](#)
 - [events](#)
 - [examples](#)
5. F
- [faq](#)
 - [feature](#)
 - [featureset](#)
 - [file](#)
 - [firmware](#)
 - [fleetwatcher](#)
 - [fleetwide](#)
 - [flyer](#)
 - [fmcsa](#)
 - [footage](#)
 - [form](#)
 - [freightliner](#)
 - [froze](#)
 - [ftp](#)
 - [fuel](#)
 - [fw](#)
6. G-H
- [geofence](#)
 - [glider](#)
 - [gps](#)
 - [graph](#)
 - [hardware](#)
 - [hd100](#)
 - [hino](#)
 - [home](#)
 - [hos](#)
 - [hostraining](#)
 - [how-to](#)
 - [howto](#)
 - [how-to-article](#)
7. I-J
- [idle](#)
 - [inactive](#)
 - [information](#)
 - [initial](#)
 - [inspection](#)
 - [instalation](#)
 - [install](#)
 - [installation](#)
 - [installations](#)
 - [integration](#)
 - [intelliroute](#)
 - [international](#)
 - [j1939](#)
 - [jbus](#)
 - [jira](#)
 - [jirareport](#)
8. K-L
- [kb-how-to-article](#)
 - [kb-troubleshooting-article](#)
 - [kenworth](#)
 - [kernel](#)
 - [kits](#)
 - [law](#)
 - [library](#)
 - [librarysync](#)
 - [line](#)
 - [list](#)
 - [location](#)
 - [lockup](#)
 - [log](#)
 - [logging](#)
 - [login](#)
 - [logo](#)
 - [logs](#)
9. M
- [mack](#)
 - [malfunction](#)
 - [manual](#)
 - [maps](#)
 - [mct](#)
 - [message](#)
 - [messaging](#)
 - [mgi](#)
 - [mileage](#)
 - [missing](#)
 - [mode](#)
 - [modem](#)
 - [modems](#)

[Add FAQ from Template - DriverTech Use only](#)

Frequently Asked Questions

- motion
 - movement
 - moving
10. N-O
- navigation
 - new
 - newcustomer
 - newrules
 - number
 - numbers
 - off-duty
 - officer
 - on-duty
 - order
 - output
11. P-Q
- part
 - parts
 - patch
 - personal
 - personaluse
 - peterbilt
 - pin
 - pins
 - plan
 - positions
 - power
 - pricing
 - printer
 - progressive
 - provision
12. R
- reference
 - register
 - registration
 - registry
 - regulation
 - reimage
 - remotecontrol
 - report
 - reporting
 - request
 - required
 - reset
 - resolution
 - responses
 - restoration
 - retention
 - rev6
 - rev7
 - roadside
 - route
 - rules
13. S
- sales
 - scanning
 - screen
 - search
 - sensor
 - settings
 - setup
 - shutdown
 - size
 - sleeper
 - software
 - source
 - speed
 - split
 - sprint
 - standard
 - startup
 - state
 - statusreport
 - sunteck
 - sunteckf
 - support
 - system
14. T
- table
 - team
 - terminal
 - time
 - timers
 - timezone
 - tnd

Frequently Asked Questions

- [touch](#)
- [touchscreen](#)
- [tpc](#)
- [trailer](#)
- [training](#)
- [transfer](#)
- [triggered](#)
- [triggers](#)
- [trip](#)
- [troubleshooting-guide](#)
- [truck](#)
- [truckpc](#)

15. U-V

- [unassigned](#)
- [unit](#)
- [update](#)
- [upgrade](#)
- [upload](#)
- [us-8](#)
- [usb](#)
- [use](#)
- [usx](#)
- [v6](#)
- [verification](#)
- [video](#)
- [videos](#)
- [view](#)
- [violation](#)
- [visor](#)
- [vnc](#)
- [volume](#)
- [volvo](#)

16. W-Z

- [warning](#)
- [watchdog](#)
- [wifi](#)
- [wiring](#)
- [workflow](#)
- [xerox](#)
- [y-cable](#)
- [zeus](#)

17. 0-9

- [3g](#)
- [4g](#)
- [6](#)
- [6-08](#)
- [6-pin](#)
- [9](#)
- [9-pin](#)

[Back to The Top](#)

[Home](#)

[Add FAQ from Template](#)