


How-to Change a GPS Location From N/A

How-to Change a GPS Location From N/A

Step-by-step guide

1. Select the date that requires a location update (indicated by a yellow star):
   a. 

2. This will show the specific status that requires correction:
   a. 

3. Select the status that you wish to change.
4. Now select the location field:
   a. 

5. Enter the location:
   a. 

6. Press "Submit" and your status will be updated.

Related articles

- How does the unit warn for Personal Use limits?
- How-to send HOS ELD logs to Enforcement Officer for Roadside Audit
- Why do I see events from other trucks on my log for today?
- Who can Certify an HOS log?
- What is Required to Trigger an Auto-Arrival (Workflow)?

Back to The Top

Home

Copyright © 2017, DriverTech LLC