

How-to Enable Turn by Turn Directions in DTNAV

Step-by-step guide

After your destination information has been entered and your route has been calculated:
From the menu, touch DTNav



1. From the map screen press on the button in the bottom right




Copyright © 2017, DriverTech LLC

How-to Enable Turn by Turn Directions in DTNAV

2. Now press on “View”



3. Now press “Turn by Turn”



4. You should now see turn by turn instructions



Related articles

- FleetWatcher, How-to Enter a Route in New DTNav
- What is Required to Trigger an Auto-Arrival (Workflow)?
- How-to change the truck number on your device
- DTNav, typing in a name that starts with "South"

Copyright © 2017, DriverTech LLC

How-to Enable Turn by Turn Directions in DTNAV

- My touchscreen is not responding. How can I fix it?

Back to The Top

Home

Copyright © 2017, DriverTech LLC