

How-to Turn On Wifi for all trucks

How-to Turn On Wifi for all trucks


Step-by-step guide

- As soon as each unit reboots that will start using the new settings and start searching for this Wifi Access Point.
- This will happen automatically and will not require any interaction from any of your drivers.
- Below are the steps used to add the Wifi Settings. You can use these same steps to add up to 10 different Secured Networks.


1. Log in FleetWatcher - <http://fw.drivertech.com/>



1. Click Management
2. Click System Settings



3. Click "Company Groups"
4. Click "Magnifying Glass"
5. Click "(Your Company Name)"



7. Click "Edit"

How-to Turn On Wifi for all trucks

Company Group Settings

Foreland Refining

Add Group Delete Group

Settings Members Assigned Terminals Assigned Managers

Name Foreland Refining * Default

Edit Copy Save Cancel

9. * Company settings are used to split a Fleet among separate operating authorities (DOT Number).
10. Scroll down
11. For your First named "Network 1:" Copy and Paste your SSID under the "SSID" column
12. For your First named "Network 1:" Copy and Paste your Password under the "Key" column

Wi-Fi Networks

☒ Wi-Fi Enabled

	SSID	Key
Network 1:	Chersonese	*****
Network 2:		
Network 3:		
Network 4:		
Network 5:		
Network 6:		
Network 7:		
Network 8:		
Network 9:		
Network 10:		

☒ Restrict Wifi Networks ONLY to ones above

* Secure WiFi is not supported on TPC rev4 due to WinXP Embedded OS deficiency
* To specify an open access point simply enter an SSID but leave the KEY field empty

- 13.
14. For your Second named "Network 2:" Copy and Paste your SSID under the SSID column
15. For your Second named "Network 2:" Copy and Paste your Password under the "Key" column
16. You may enter 1 or up to 10 different Networks setup.
17. Scroll up
18. Click Save

Company Group Settings

Foreland Refining

Add Group Delete Group

Settings Members Assigned Terminals Assigned Managers

Name Foreland Refining * Default

Edit Copy Save Cancel

a. * Company settings are used to split a Fleet among separate operating authorities (DOT Number).

Related articles

- [How-to Turn On Wifi for all trucks](#)
- [No Communication](#)
- [How-to Install a Truck PC Antenna](#)

[Back to The Top](#)

[Home](#)