What new information is on the Drive-Safe screen with 6.01.04+?

Question:

What New information is on the Drive-Safe screen with 6.01.04+?

DTCore version 6.01.04+ has a new Drive-Safe screen enabled to show more timers so the driver is able to more accurately manage their time even with a Co-Driver involved

Answer:

The new Drive-Safe screen shows these timers:

Driving: How much time the driver has to drive until their next violation
70hr: How much available time the driver has for his 70 hour Total On-Duty timer
11hr: How much available time the driver has for his 11 hour driving timer
14hr: How much available time the driver has for his 14 hour On-Duty timer
8hr: How much available time the driver has for his 8 hour Mandatory Break timer
Hrs back: How much time the driver will "get back" after the logs are recalculated at midnight
Co-Driver: Allows the ability to see a Co-Driver's timers if there is a Co-Driver assigned to the driver's logs for the current day



Related articles

- How does the unit warn for Personal Use limits?
- How-to send HOS ELD logs to Enforcement Officer for Roadside Audit
- Why do I see events from other trucks on my log for today?
- Who can Certify an HOS log?
- What is Required to Trigger an Auto-Arrival (Workflow)?

Back to The Top

Home

Copyright © 2017, DriverTech LLC