How do I find my truck number in the DT unit?

Question:


How do I find my truck number in the DT unit?

Answer:

1. From the main menu, tap the SysInfo button



2. In the SysInfo screen, tap the Diagnostics tab at the upper-right



3. Tap the Device Info button



How do I find my truck number in the DT unit?

4. In the next screen, you will see "Truck#"



Related articles

- How does the unit warn for Personal Use limits?
- How-to send HOS ELD logs to Enforcement Officer for Roadside Audit
- Why do I see events from other trucks on my log for today?
- Who can Certify an HOS log?
- What is Required to Trigger an Auto-Arrival (Workflow)?