## **Landmark and Geofence Events**

Provides summary and detail of Landmark Geofence Entry, Duration and Exit Events

- Requirements
- Grid Layout
  - Landmark Events Summary Row & Individual Event Row
    - Summary Row:
    - Individual Event Row(s):
- Customize Columns
  - ° Reorder, Add and/or Remove any columns on the Summary Rows by click on the 'Columns' button
  - Reorder, Add and/or Remove any columns on the Individual Event Rows by click on the "button

Landmark Events will only be generated from ELD running v6.06+



## Landmark Events Summary Row & Individual Event Row

The Landmark Events grid is made up of the main 'Parent' Events Summary Rows and the sub-grid 'Child' Individual Event Rows (see image above).

## **Summary Row:**

The parent Summary Row contains the summary information of a particular Landmark for the entirety of time spent inside the Landmark.

## Individual Event Row(s):

The child Individual Event Row(s) contain the single event that triggered on the parent Landmark. There are 4 main individual event types:

- Landmark Entry Event
- Landmark Exit Event
- Day Split Time crossed the midnight boundary of the day while inside the Landmark
- Z Detention Landmark Detention Event triggered

Many columns are sort-able, see image instructions below on how to further customize the columns:

