


How can I change the backlight/volume on my TruckPC?

Question:


How can I change the backlight/volume on my TruckPC?

Answer:

- To adjust the backlight or volume on your device, select the **SysInfo** icon on the TruckPC **Main Menu**. This will bring you to a *Settings* tab.



- Here, you can select to adjust the screen's brightness/volume by touching the **Down and Up** buttons. You can also touch and draw your finger across the percentage box.



- Touching "Low" for the backlight settings dims the screen to 1%.
- Touching "Off/Mute" will shut off the backlight/volume completely.
- If you have touched "Off" on the backlight, press the physical button that says "Menu" to bring the screen back up to the same brightness it was at BEFORE the "Off" button was touched.

Related articles

- [My touchscreen is not responding. How can I fix it?](#)
- [How-to Calibrate Your Screen](#)
- [Green Power light is on - Display is Blank](#)
- [Bad Touch Screen](#)
- [No Power](#)

[Back to The Top](#)

[Home](#)