

How-to Change a GPS Location From N/A

How-to Change a GPS Location From N/A

Step-by-step guide


1. Select the date that requires a location update (indicated by a yellow star):



US-8  Logs Options				
Date	Miles	Off-duty	S.B.	D
 06/22	0.0	09:52:02	00:00:00	0
06/21	86.5	15:05:19	00:00:00	01
 06/20	0.0	24:00:00	00:00:00	01

a.

2. This will show the specific status that requires correction:



<< Back Neil_Peart_SR

Summary Graph  List US-8 Violations Ur


Prev Next View Classic

Time	Status/Remark
 00:00:00	Off-duty - End of Shift

a.

3. Select the status that you wish to change.

4. Now select the location field:



<< Back

Time 00:00 More... DVIR


Status Off-duty

Location No GPS

Remark End of Shift

a.

5. Enter the location:



<< Back Enter location salt lak

Salt Lake City, UT

& 1 2 3 4 5 6 7 8 9

@ Q W E R T Y U I O

a.

6. Press "Submit" and your status will be updated.

Related articles

- [How does the unit warn for Personal Use limits?](#)
- [How-to send HOS ELD logs to Enforcement Officer for Roadside Audit](#)
- [Why do I see events from other trucks on my log for today?](#)
- [Who can Certify an HOS log?](#)
- [What is Required to Trigger an Auto-Arrival \(Workflow\)?](#)

[Back to The Top](#)

[Home](#)