DTNav, typing in a name that starts with "South"


Question:

Why are my search results stuck when typing in "South" to start my City search in DTNav?

Answer:

There is a City called "Southhampton" that has no space in it.

1. Using the example City: South San Francisco, start typing in "South"



3. Back in the City screen, tap the Space key



4. A list of cities with a space after "South" will now appear.



5. You can now select the desired City/State

Related articles

- · How does the unit warn for Personal Use limits?
- How-to send HOS ELD logs to Enforcement Officer for Roadside Audit
- Why do I see events from other trucks on my log for today?

DTNav, typing in a name that starts with "South"

- Who can Certify an HOS log?What is Required to Trigger an Auto-Arrival (Workflow)?