

# Frequently Asked Questions

- [About FleetWatcher and Using It](#)
  - [FleetWatcher, \(Checklist\) New Customer Setup](#) — Checklist for new customer FleetWatcher setup.
  - [FleetWatcher, How does it determine which speed reading will be reported?](#) — An explanation of how FleetWatcher reports speed data.
  - [FleetWatcher, How do I make a form or macro?](#) — A link to instructions concerning how to create a form/macro in FW.
  - [FleetWatcher, How often do HOS logs and Events and Positions update?](#) — How HOS and Events and Positions are updated on FleetWatcher.
  - [FleetWatcher, Is There a Basic Template for Terminal Settings Changes?](#) — A basic template for making terminal settings changes in FleetWatcher.
  - [FleetWatcher, Where do I find the yearly miles driven for a truck/driver?](#) — How to find a vehicle/driver yearly miles
  - [FleetWatcher: Can I enter a driver's name containing punctuation?](#) — Entering driver names into FleetWatcher
  - [FleetWatcher: Why do I see white loading screens and secure content popups?](#) — Fixing white loading screens and security messages in FleetWatcher.
  - [FleetWatcher. Where are the Reports, and how are they used.](#) — What the reports in FleetWatcher do
  - [How does Unassigned Driving Work?](#) — How unassigned driving works and applies to the driver's logs if applicable
  - [How do I add remarks to a driving status?](#) — Adding remarks to a driving status
  - [What baud are DriverTech units set up for?](#) — What baud for DriverTech units?
  - [Which Web Browsers for FleetWatcher Does DriverTech Support?](#) — FleetWatcher: Which web browsers are supported
  - [Why are my Personal Use miles not resetting?](#) — How to reset Personal Use miles for HOS logs
  - [Why are unassigned driving events \(and other events\) showing up on the logs of multiple drivers?](#) — How driving events appear on different driver's logs
  - [Why does the Personal Use Report have instances with 0 miles?](#) — Explanation of how a Personal Use record could show 0 miles on the Personal Use Report.
  - [Why do I see events from other trucks on my log for today?](#) — Lists the FMCSA article and explanation for status events on a driver's log for multiple trucks.
  - [Why do the HOS logs stop halfway through the day?](#) — Brief explanation of what causes a log to stop part-way through the day
- [About the ELD and Using It](#)
  - [Can an ELD be set to 15 minute time intervals?](#) — Explanation of time intervals handled by the ELD
  - [Can I change a Driving status to a Non-Driving status?](#) — Explanation of driving status
  - [Does DriverTech's ELD have Anti-Virus software?](#) — Anti-virus handling by the ELD
  - [DTNav, typing in a city name that starts with "South"](#) — Entering a City/State into DTNav
  - [Health Check](#) — Performing a Health check from Sys Info
  - [How are Speeding Alerts Created?](#) — How speeding alerts are created.
  - [How can a driver combine their on-duty not driving status on an ELD, with Driving?](#) — Process for combining On-Duty with Driving status
  - [How does the TruckPC detect driving?](#) — States how the TruckPC detects driving/movement from the truck
  - [How does the Truck PC go from Driving to On-Duty automatically?](#) — Going from Driving to On-Duty automatically
  - [How do I use the Agricultural Exemption](#) — Using the AG exemption
  - [How do the HOS Timers calculate?](#) — A brief explanation of the timers/clocks in HOS
  - [If I turn the TruckPC off and start driving, will it record my drive time?](#) — How the ELD auto-records drive time
  - [I received a low memory warning. What should I do?](#) — What to do when receiving a low memory message on the unit
  - [Manually Submit HOS Logs from the ELD](#) — ELD: Submitting HOS logs
  - [Unit Icon Legend: What does this icon represent?](#) — What the various icons mean in the ELD
  - [What can I do if my unit cannot send or receive messages?](#) — Troubleshooting messaging issues.
  - [What does a driver need to do when they see diagnostic errors?](#) — FMCSA regulations on driver responsibilities when they see diagnostic errors.
  - [What does the driver do on their end to register a DT unit?](#) — Registering the ELD on the driver's end
  - [What do the icons in the Log Overview report mean?](#) — Fleetwatcher: Identifying the diagnostic icons
  - [What is "Yaw Control via Engine" and "YC Brake Control"?](#) — An explanation of yaw control via engine and YC brake control.
  - [What is automatically recorded by the ELD?](#) — Explanation of the data recorded by the ELD automatically
  - [What is Required to Trigger an Auto-Arrival \(Workflow\)?](#) — What triggers an auto-arrival in workflow?
  - [What should I show a DOT officer while being inspected?](#) — Explanation of what to show a DOT officer when being inspected
  - [What triggers an event that is recorded by the camera?](#) — Listing of the events that trigger a video from a camera
  - [What were the 4 main HOS rule changes added in Sept. 2020?](#) — Related articles
  - [When do my logs/current totals update?](#) — Explains when the logs and current totals update in FleetWatcher
  - [When I press anywhere on the screen, only the bottom left corner lights up.](#) — When only the symbol key lights up when touching anywhere on the screen
  - [Where Does State Mileage go if a Unit Was Unplugged While Crossing State Lines?](#) — An example explaining state mileage in regards to sensor jumps.
  - [Which software version is my unit running?](#) — How to locate your unit's software version.
  - [Who can Certify an HOS log?](#) — FMCSA regulation on the certification of HOS logs
  - [Why am I being auto-removed from Yard Move?](#) — Brief explanation: how the driver is removed from Yard Move automatically
  - [Why am I not able to use the Co-Driver feature?](#) — Information on the functionality of the Co-Driver feature
  - [Why are my State Miles Showing on the Wrong Date?](#) — How to troubleshoot the State Mileage Report data
  - [Why can't I add a status when I stop driving?](#) — Brief explanation: how to enter an on-duty status after driving has ended
  - [Why is my unit shutting down while I'm driving?](#) — Lost power while driving?
  - [Why was I put on the drive line before I started driving?](#) — An explanation of how the unit decides "driving" status.
  - [Why wont my TruckPC turn on?](#) — Troubleshooting steps for a unit with no power.
- [General](#)
  - [Does DriverTech have a data restoration policy?](#) — Explanation of DriverTech's restoration policy
  - [How do I know that DriverTech's ELD is registered with the FMCSA?](#) — FMCSA Registered/Approved devices
  - [How long are Hours of Service records retained?](#)
  - [How-to login to DTMobile](#) — When attempting to login to the DTMobile App
  - [What are the different types of Malfunctions and Diagnostic Events?](#) — List of the different types of Malfunctions and Data Diagnostic Events
  - [What are the exceptions to the HOS regulations?](#) — Explanation of the various exceptions to the HOS rules
  - [What are the most commonly used Idle fields?](#) — Idle fields used by the ELD
  - [What constitutes a long/mid/short idle in the reporting?](#) — Idle times explained.
  - [What is DriverTech's recommendation as far as Hydra or Deutsch cables?](#) — Explanation of which cables are recommended by DriverTech
  - [What is DriverTech's recommendation as far as Yard Move and Personal Use.](#) — Yard Move and Personal Use settings recommended by DriverTech
  - [What is the FMCSA's definition of Harassment?](#) — Harassment and Coercion as defined by the FMSCA
  - [What is the RMA diagnostic fee?](#) — Explanation of the diagnostic fee DriverTech charges
  - [Where can I find the details on my current trip?](#) — Brief steps for locating trip information.
  - [Which is the current software version?](#) — A list of the latest software (DTCORE) versions.
  - [Who must comply with the ELD rule?](#) — Explanation of who must comply with the ELD rule