

Copilot Not Getting GPS While GPS Locations are Working

Copilot Not Getting GPS While GPS Locations are Working

Problem:

The unit's GPS appears to be functioning but Co-Pilot is not showing the correct location.

Solution:

1. Please call ALK to report Issue.
2. This link (<http://copilotpro.com/us/contact/>) and filling out their form.
3. You can also reach them over the phone at: 609.683.0220 or 877.573.0138

DriverTech's Technical Support Line: 866-331-8785

Related articles

- [What is Required to Trigger an Auto-Arrival \(Workflow\)?](#)
- [No cell - MS is not currently searching - Driver](#)
- [No cell - MS is not currently searching - Dispatcher](#)
- [Co-Pilot Error Messages](#)
- [How-to Disable Speed Alerts in DTNav](#)

[Back to The Top](#)

[Home](#)