

# Vehicle Administration

The Vehicles feature displays information regarding your company's vehicles.

- [VIN](#)
- [Manual VIN](#)
- [Terminal](#)
- [License Plate](#)
- [License Plate Jurisdiction](#)

You do not need to manually enter any data into the Vehicles feature; vehicles equipped with an activated and registered in-cab device will be displayed here automatically.

You can select to view vehicle information in a report format. Select to view report by **Vehicle**, **Vehicle Group**, or **All**.

## VIN

VIN reported from the vehicle's JBus or the user manually supplied VIN (will be flagged as Manual VIN).

## Manual VIN

Indicates the VIN was manually supplied by user (NOT from vehicle's JBus).

## Terminal

The terminal the vehicle is assigned to.

## License Plate

User entered License Plate number.

## License Plate Jurisdiction

User entered state the vehicle works out of.