

# How can a driver combine their on-duty not driving status on an ELD, with Driving?

**Q: How can a driver combine their on-duty not driving status such as working in a warehouse, on an ELD, prior to operating a commercial motor vehicle equipped with an ELD?**

**A:** All of the driver's hours of service must be accounted for when subject to the HOS rules. Prior to operating a commercial motor vehicle equipped with an ELD, the driver can manually add any on-duty not driving status.

1. When selecting an On-Duty status, there are several remarks to choose from. If none of these apply, you can select Other.

The screenshot shows the 'Select Remark' screen in the ELD application. At the top, there are navigation buttons: '<< Back', 'Select Remark', '<<', '1/1', and '>>'. Below this is a grid of remark options: 'Beginning of Shift/Pre-trip', 'Fuel Stop', 'Exemptions...', 'Inspection...', 'Mechanical', 'Compliance', 'Load', 'Detention', 'Accident', 'Unload', 'Customer Check In/Out', 'Other' (highlighted with a red box), 'Drop and Hook', and 'Training...'. At the bottom, there is a status bar with 'Menu', 'HOS 04:33', a clock icon, a signal strength indicator, '16:12', and a printer icon.

2. You can then enter a custom duty remark, then select Submit.

The screenshot shows the 'Enter duty status remarks' screen. At the top, there are navigation buttons: '<< Back' and 'Submit'. Below this is a text input field with the label 'Enter duty status remarks' and the text 'WAREHOUSE' entered. Below the text field is a numeric keypad with letters assigned to the numbers (e.g., 1 is '&', 2 is '1', etc.). At the bottom, there is a status bar with 'Menu', 'HOS 04:33', a clock icon, a signal strength indicator, '16:12', and a printer icon.

3. If the summary appears correct, select Submit.

The screenshot shows the summary screen in the ELD application. At the top, there are navigation buttons: '<< Back' and 'Submit'. Below this is a summary of the current status: 'Time: 16:12', 'Status: On-duty', 'Location: West Valley City, UT', and 'Remark: WAREHOUSE'. At the bottom, there is a status bar with 'Menu', 'HOS 04:29', a clock icon, a signal strength indicator, '16:17', and a printer icon.

Drivertech's Technical Support Line: 866-331-8785

# How can a driver combine their on-duty not driving status on an ELD, with Driving?

## Related articles

- [Why did my workflow go to my Inbox and not my Work tab?](#)
- [Why can't I add a status when I stop driving?](#)
- [Why am I being auto-removed from Yard Move?](#)
- [Who can Certify an HOS log?](#)
- [What triggers an event that is recorded by the camera?](#)