

# My unit is showing the wrong time. How can I fix it?

## Question:

My unit is showing the wrong time. How can I fix it?

## Answer:

Timezone settings are based on Terminal Group settings in FleetWatcher. In order to ensure that your unit is displaying the correct time, you should move your truck number and driver ID into a Terminal Group that is set for your preferred Timezone. This can be accomplished by an authorized FleetWatcher user.

Drivertech's Technical Support Line: 866-331-8785

## Related articles

- [How does the unit warn for Personal Use limits?](#)
- [How-to send HOS ELD logs to Enforcement Officer for Roadside Audit](#)
- [How-to Add a Company and Terminal](#)
- [FleetWatcher, How-to Enter a Route in New DTNav](#)
- [Why do I see events from other trucks on my log for today?](#)

[Back to The Top](#)

[Home](#)